



# Axis Vaxtor LPR Integration App-note

## Contents

1. Introduction.....	3
1.1 CathesisVision Requirements.....	3
1.1.1 Software .....	3
1.1.2 License Requirements .....	3
1.2 Integration Components .....	4
2. Axis Vaxtor Setup.....	5
3. Device Addition and Configuration .....	8
3.1 Add a Camera .....	8
3.2 Devices Section (Add a New Device in CathesisVision) .....	9
3.2.1 Device Addition .....	10
3.3 Configuration Section (Tabs) .....	10
3.3.1 Object Configuration Tab .....	10
3.3.2 Object Properties Tab.....	11
3.3.3 Device Events Tab.....	11
3.3.4 Object Groups Tab.....	12
3.3.5 General Tab .....	13
3.3.6 License Plates Tab.....	14
4. Database .....	22
4.1 Navigate to the database .....	22
4.1 Database Interface .....	23
4.1.1 Viewing an entry's associated recording.....	24
5. Events .....	25
5.1 Event window .....	25
5.2 Creating an event .....	25
6. Conclusion .....	26

While Cathesis has made every effort to ensure the accuracy of this document, there is no guarantee of accuracy, neither explicit nor implied. Specifications are subject to change without notice.

# 1. Introduction

This document details the integration of the Axis Vaxtor LPR application with CathesisVision LPR interface. The Axis Vaxtor LPR is an app that is installed onto a camera. The information captured by the Vaxtor app is then sent to the CathesisVision system through the CathesisVision LPR interface.

**Note:**

1. For information regarding the regular operation of the Vaxtor LPR application, please consult the relevant manufacturer’s documentation.
2. Cameras are configured in CathesisVision as standard IP cameras and are recognised as an LPR camera.
3. The camera being used for LPR and the site NVR should be properly synced to the same time source with the same time zone.
4. For more information on CathesisVision ANPR/LPR integration, consult the ***CathesisVision Number Plate Recognition Integration Guide***.

## 1.1 CathesisVision Requirements

### 1.1.1 Software

- CathesisVision 2020.4 and later.
- Windows 10: 64-bit and later; Windows Server 2016 and later.
- Minimum of 4GB of RAM required.

**Note:** if the user plans on installing this integration on a Linux unit, contact [support@cat.co.za](mailto:support@cat.co.za).

### 1.1.2 License Requirements

License Name	License Description
CLPR-2000	Integration Base License
CLPR-1001	Per Detector License

**Note:** in this integration, individual devices will require a camera IP license and a Detector license for each LPR camera. The site will require a single base license.

#### A NOTE ON CAMERA CHANNELS

The CathesisVision software packages have **limits on camera channels**. A multi-head camera is physically a single device (camera) but it **requires a camera channel for each one of the internal cameras**. The same applies to an encoder: a 16-channel encoder will account for 16 camera channels on the CathesisVision software, even though it is a single device.

## 1.2 Integration Components

All CathesisVision integrations have two component levels: **Device** and **Object**.

**Device** The device is CathesisVision software's interface, which handles all the interaction between CathesisVision and the integrated hardware. When an integration is added to the CathesisVision system, a device is added. The messages received from the device are called Device Events.

**Objects** Objects are the individual pieces of hardware that comprise the integration. There may be multiple "object types" under the objects group. For example, the main controller and door nodes, of an access control system, are both objects. There are different types of objects.



### USEFUL LINKS

To view **tutorial videos** on CathesisVision setup, visit <https://cathesisvideo.com/resources/videos>

Find answers to Cathesis **Frequently Asked Questions**: <https://cathesis.crisp.help/en/?1557129162258>


## 2. Axis Vaxtor Setup

1. Select the Axis Vaxtor Setup via the web interface using the camera IP address.
2. Navigate to **Apps** and select the **VaxALPR On Camera** Application.




3. Make sure the VaxLPR app is version **2.2-20**.

### VaxALPR On Camera - MMC




3. From the drop-down menu, navigate to **Reporting**.



## Reporting



4. Under the Reporting menu Open the **TCP Server** option.



5. Make sure the **port** number is set to 5000.

Port

5000

6. The text provided below must be copied and pasted into the message section. It is important to copy the text exactly as below in order for Cathexis to receive the data.

**Highlight** and **copy** the following string:

[START]\$plate\$|\$confidence\$|\$country\$|\$date\$|\$left\$|\$top\$|\$right\$|\$bottom\$[IMAGE]\$image\$[END]

**Paste** into the **message** section, which looks like this:

Message


[START]\$plate\$|\$confidence\$|\$country\$|\$date\$|\$left\$|\$top\$|\$right\$|\$bottom\$[IMA

## 3. Device Addition and Configuration


This section details the procedure for setting up CathexisVision LPR integration and Axis Vaxtor LPR application to communicate with each other effectively.

### 3.1 Add a Camera

The first step is to add the Axis Camera by selecting **Servers / Cameras / Right-click / New**.




The **Axis camera's driver, and IP address** are listed below:






### 3.2 Devices Section (Add a New Device in CathesisVision)

Integrations are added on a server-by-server basis. They are managed in the Integration Devices panel, under the **Setup Tab** of the servers to which they are added. To get to the Integration Panel, follow this path:




Select the Cathexis LPR Driver.




There are two sections in the Integration Panel.


The **Devices** list will list the integration devices that are attached to the server.



The **Configuration** section enables editing/reviewing, the device selected in the **Devices** section.

### 3.2.1 Device Addition

1.  Once in the Integration Panel, click on **New device** in the Devices section. This will open the addition dialogue.
2. Select **Cathesis LPR** driver from the list.




Give the device a descriptive **name**.

## 3.3 Configuration Section (Tabs)




The configuration section is divided up into a number of tabs. These tabs are: **Object configuration**, **Object properties**, **Device Events**, **Groups**, and **General**.

### 3.3.1 Object Configuration Tab







The object configuration tab is the tab where all the individual objects that comprise the integration may be viewed.

### 3.3.1.1 Object Configuration Buttons


-  Click on **New** to add a new object.
-  Click on **Edit** to open up an existing object for editing.
-  Click on **Delete** to delete an existing object from the CathesisVision configuration.

### 3.3.1.2 Object Configuration Right-click Options

-  **New** will open up the dialogue box to add a new object.
-  **Disable/Enable** allows manually enabling/disabling individual objects.
-  **Delete** will permanently remove this object from the list.
-  **Properties** will open up the object properties. Edit the object from here, specifically, assign cameras to this object, as well as define user access levels for it.

## 3.3.2 Object Properties Tab

The object properties tab is where all object properties may be viewed.




## 3.3.3 Device Events Tab



This lists all Events sent from the device. It is an excellent way for installers to see that the integration is functioning, and to monitor the Events happening on site.


### 3.3.4 Object Groups Tab



Create groups of the same type of object.



**Tip:** This is very useful when setting up Events, because Events can be triggered by an object group. (For example, a group will trigger, if any of the devices in that group is triggered.)

#### 3.3.4.1 Create a group





-  Click to create a group.
-  Click to edit a group.

**Note:** Once a group has been created, the object type of the group may not be edited.


Give the group a descriptive **Group name**.

Click on the drop-down menu to select the **Object type** to group.

A list of Available Objects will appear. Multiple objects may be selected at a time.

-  To add these objects to the group, select them and click this arrow.
-  To remove these objects from the group, select them and click this arrow.


### 3.3.5 General Tab



Currently the general tab deals with the **Integration database**. Here, select an existing database, or configure a new database for the integration.


**Note:** Each integrated device needs to be attached to an Integration database. Without setting up/adding a database here, the integration will not function properly within the CathesisVision system.

#### 3.3.5.1 Configure a new database




If a database is not yet created, clicking on this button will navigate to the integration database setup.


#### Initialise the integration database



The first time an integration database is added, initialise this feature on the unit. This will add a broad database, within which all of the integrated device's databases will be added.

 Select the unit to which to add the database from the list on the left. Click **Initialise integration database**.

Choose which partition the database will be formed on, and select how much space it will take up.




### Add a new devices database

After initialisation, add the database for the integration being worked with.



Click on the **New** button, at the bottom of the **Create database** window.




Give the Integration database a descriptive **Database Name**. For example, Container.

Allocate a **Size** to the new device database.

Choose the device **Driver** that the device will be using. Click on **OK** to create the database.

#### 3.3.5.2 Select the integration database

Be sure to select the Cathexis LPR v3 (1.1.2).




Integration database -- select integration database --

Once a database has been created, the user may select it by clicking on the **gear icon**, and selecting it in the dialogue that appears. Only databases which relate to the device being added should appear.


### 3.3.6 License Plates Tab

In the License Plates tab, **license plates** and license plate groups can be created, and **traffic rules** and **plugins** can be configured.


The three icons on the left-hand panel can be used to navigate to these options.



### 3.3.6.1 License Plates Section






Click the drop-down menu to change how the license plates are displayed:




Display all license plates, or certain groups of license plates (if created).

#### License Plate Groups


-  Create new license plate group.
-  Edit name of existing license plate group.
-  Delete license plate group.


**Tip:** Groups are useful when setting up traffic rules. See below.

Once a group is selected, license plates may be added to it:



#### Create/import license plate

 Click to import an existing license plate list in CSV format.

 Click to create a new license plate. See below.

## New License Plate

Fill in the meta-information associated with the license plate.

Add a reference image if necessary. This may be, for example, a picture of the driver or of the car.

### 3.3.6.2 Traffic Rules Section

Traffic rules can be configured to generate messages when defined traffic patterns are detected. For example, a rule can be configured to generate a message if a license plate is seen multiple times at a given location in a certain period. Currently there are four rules:

- **Visit location:** triggers if a license plate is seen at the same location multiple times.
- **Visit area:** triggers if a license plate is seen at multiple locations in a given time period.
- **Average speed:** generates an event based on the average speed of a vehicle between two points.
- **Loitering traffic:** triggers if a license plate has been in an area for too long.



## New Rule

Click **New** to add a new traffic rule.

### New rule

Give the traffic rule a descriptive name. Select the kind of rule to apply. See above for rule descriptions. The settings options will change depending on which rule is selected. See below for appropriate rule.

## Visit Location Rule

### Rule Tab

Set the **number of visits** that will trigger the rule. Set the **period of days or hours** in which these visits must occur to trigger the rule.

### Locations Tab

Select the locations to be checked. These locations are the sites at which the ANPR detectors are installed.

### License Plates tab

If license plate groups have been created, they can be included in, or excluded from, the rule.

See the License Plates section for details on creating license plate groups.

## Visit Area Rule

### Rule Tab

Set the **minimum locations** that a license plate must visit in order to trigger the rule. Set the **period of days or hours** in which these visits must occur to trigger the rule.

### Locations Tab

Select the locations to be checked. These locations are the sites at which the ANPR detectors are installed.

### License Plates Tab

If license plate groups have been created, they can be included in or excluded from the rule.

See the License Plates section for details on creating license plate groups.

## Average Speed Rule

### Rule Tab

Set the locations between which the average speed will be detected. These locations are the sites at which the ANPR detectors are installed.

**Note:** To edit the speed settings (from mph or kph), it is necessary to edit the regional system settings. See note following\*

### Direction


Select a direction between locations, or both.

### Distance


Select the distance of detection.

**\*Note:** displaying speed in Miles per hour or Kilometres per hour.

1. Visit Control Panel.




2. Click on *Change date, time, or number formats* to change the region.




3. To display the reading in **mph**, change the regional system settings to **English (United States)**. To display the reading in **kph**, change the regional system settings to **English (United Kingdom)**.




4. Move to *Administrative* tab and click on *Copy Settings*.



5. Check *Welcome screen and system accounts* and check *New user accounts*. Click **OK** to save.




## Loitering Traffic Rule



### Rule Tab

Select the **entry/exit cameras**. It is possible to select multiple entry/exit cameras.

**Adjust the maximum time** a license plate is allowed within an area, and at which point an alert will be sent according the system's configuration. The maximum time can be set from 1 minute to 24 hours.




### License Plates Tab


If license plate groups have been created, they can be included in or excluded from the rule.

See the License Plates section for details on creating license plate groups.

### 3.3.6.3 Plugins Section




Click **New** to configure new plugin.



to edit plugin.



to delete plugin.



Give the plugin a descriptive name.

Choose the plugin type from the drop-down menu.

#### Push Notifications Tab

Check  **Enable** to enable push notifications.

Enter the **IP address**.

Enter the **Port number**.

Enter the **Username and Password**.

Set a **ping** frequency.

Select to send plate image.

Select to send frame image.

Select to send meta-information (if available).

#### HTTP Server Tab


Check to enable, and set port number:

**Enable**

Port


## 4. Database

The database tab allows one to navigate to the databased entries, for each individual database. In the database tab, each database is presented as a table. It has built-in filters, and the ability to navigate by timestamp. If a database entry has an associated recording, it is possible to launch this recording, from within the database tab.




Most integrations will have a different database presentation, and unique filters, due to the different parameters sent by the integrated device to CathesisVision.

### 4.1 Navigate to the database



View the information stored in the Integration database, by following the path seen to the left.

This navigates to the Database Tab.











When the database tab opens, select the relevant integration database from the database panel that opens on the left-hand side. The databases are ordered under the NVRs that they are attached to.

To open and close this list, click on the arrow in the centre of the list:




## 4.1 Database Interface




① <b>View</b>	<b>View</b> changes the way the database is presented. 
② <b>Sorted By</b>	Events may only be sorted by Time .
③ <b>Easy Search</b>	The easy search option quickly searches the database. The options are License plate, License Plate (Partial Match), Group, LPR Detector.
④ <b>Filter</b> 	<p>Filter offers a more advanced manner of sorting information in the Integration Database table.</p> <p>Once the filters dialogue is open, these are the options:</p> <p><input checked="" type="checkbox"/> <b>Enable filters</b>    Check this box to enable filters.</p> <p>    Click on this icon to <b>add</b> a new filter.          The filter icon will change when filters are active.  → </p> <p>    Click on this icon to <b>delete</b> an added filter.</p> <p><b>Note:</b></p> <ol style="list-style-type: none"> <li>Multiple filters may be run simultaneously.</li> <li>The same parameter may be used more than once.</li> <li>To change a filter click on the blue hyperlinked text.              (For example, click on <a href="#">Timestamp</a> to change the filter from Timestamp, to any of the other available options.)</li> </ol>
⑤ <b>Export</b>	Generate metadatabase reports in PDF or CSV format. See below.
⑥ <b>Manage Reports</b>	Generate scheduled metadatabase reports. See below.
⑦ <b>Go to Time</b>	This navigates to a specific point in time, down to the second.  To navigate to a timestamp set the time using the time and date boxes, and then click on the <b>arrow</b> icon.

### 4.1.1 Viewing an entry's associated recording

This integration uses the new video option where the video player is embedded in the database view. This player uses the same timeline features as the CathesisVision cameras tab.

To view an associated recording, simply left-click on a database entry, which has the  icon in the **Links** column. Then click play in the video player.





## 5. Events

A CathesisVision Event has a trigger, which causes an action. Integrated devices may be set to act as triggers, or as actions. This document will detail the Cathesis LPR / Vaxtor Container specific aspects of Events. There is a comprehensive guide to CathesisVision Events in the main setup manual.

Most of the data that CathesisVision receives from a device is presented in the **Events interface**. This is done in order to give the user a full range of options. As a result, some of the options presented in the interface may be impractical as event triggers, or actions.

### 5.1 Event window

Events in CathesisVision are set up via the Event Window. This has 4 tabs: in the **General Tab** an event is given a name, description, schedule and priority; in the **Triggers Tab** the trigger/s for the event is/are defined; in the **Actions Tab** the action/s, which the event takes, is/are defined; in the **Resources Tab** the various site resources, which can be used as part of an event, are defined.

#### New Event


Window Broken

The screenshot shows the 'New Event' dialog box with the 'General' tab selected. The fields are as follows:

- Name:** Window Broken
- Description:** (Empty text box with a help icon)
- Schedule:** Always (with a dropdown arrow and icons for schedule editing)
- Priority:** Low (with a dropdown arrow and a warning icon)

### 5.2 Creating an event

To create an event using the Cathesis/Vaxtor device, enter the **Events management area**:



Once in the Events management area, click on **New**. This will open up the New Event window.

## 6. Conclusion

This app-note was designed to deal specifically with this integration.

For further information about the CathesisVision software, consult the ***CathesisVision Setup Manual*** (<http://cathesisvideo.com/>). For support, email [support@cat.co.za](mailto:support@cat.co.za).